



rapidresponse™

OPERATING INSTRUCTIONS

24hr Segment Timer



IMPORTANT SAFEGUARDS AND PRECAUTIONS



SAVE THESE INSTRUCTIONS

- Read all instructions carefully
- For Household Use only. Not intended for commercial use.
- Only for use indoors.
- Do not use outside or in damp conditions.
- Before plugging into mains socket, check whether supply line voltage and current rating are in compliance with the rated electrical parameters shown on the rating label.
- Do not use for appliances over 13a or 3kw.
- Do not use for any purposes other than the appliances intended use.
- Do not use if any part of this appliance is damaged in any way.
- Always unplug when not in use.
- To prevent against the risk of electric shock, do not submerge any part of this appliance in water, unless advised in this manual.

Note: We don't recommend heating appliances to be connected to timers.

- This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.
- Children shall not play with this appliance.
- Cleaning and user maintenance shall not be made by children without supervision.

OPERATION

YOUR 24HOUR PLUG-IN TIMER WILL SWITCH PLUGGED-IN APPLIANCES UP TO 13 Amps or 3KW. It is easy to use – it simply plugs in to a standard 240v 13 Amp AC mains socket, so that no wiring is needed!

Ideal for security, economy and convenience, you timer can be used, for instance, to:

- Control the switching ON and OFF of lighting in the home, even while you are away – for added security!
- Operate appliances such as washing machines, dishwashers, heaters, etc at "low cost" electricity periods.
- Control heating more effectively and economically.
- Turn appliances such as TV's, heaters, etc, OFF automatically, as a fail safe facility.

OPERATION

1. PROGRAMMING-SETTING "ON" AND "OFF" SWITCHING PERIODS.

The permanent, non-removable captive time segments simply lift up for "OFF" and push back down for "ON" Each time segment represents a 15 minute switching period (either ON or OFF depending on its position). 4 segments represent 1 hour. The timer has a total of 96 segments (96x15 mins equals 1440 mins or 24 hrs).

The plugged-in appliance will now operate only during the times denoted by the pushed-in time segments.

CAUTION: The wattage of appliances being controlled should not exceed the capacity of this Timer.

NOTE: This Timer is intended for INDOOR USE ONLY.

2. TO SET THE ACTUAL TIME

Rotate the dial clockwise, in the direction of the arrows, until the correct time of day is set against the arrow head (time set marker).

Check that the programmed time segments have not been accidentally pushed down while rotating the dial! Ensure that the BLACK Manual Override Switch is set to "0". When "0" is showing, the Timer will operate to your pre-set program.

3. PERMANENT "ON" SWITCH - MANUAL OVERRIDE

Slide the BLACK manual override switch to "1" (ON). The plugged-in appliance will now be switched "ON" permanently, without upsetting the programming segments.

SPECIFICATIONS

Operating Voltage:	220-240V
Frequency:	50HZ
Switching Current:	13 AMP (Resistive) 2 AMP (Inductive)
Switching Load:	3000W
Min.Switching Interval:	15 MINUTES
Working Temperature:	-10C TO + 55C
Switching Accuracy:	+/- 15 MINUTES



rapidresponse™

CUSTOMER SERVICES

If you have any queries about this product. Please contact our customer service helpdesk:

web: www.lloytronhelpdesk.com



To find more details on a wide range of Rapid Response products please visit our website at www.lloytron.com
Lloytron plc, Laltex House, Leigh Commerce Park, Greenfold Way, Leigh, Lancashire, WN7 3XH. England, U.K