
OPERATING INSTRUCTIONS

Rechargeable
**1w Superbright
LED
Spotlight**



MODEL: D1001BK

If you have any queries about this product, there are three ways to contact our customer service department:

 **08454 81 8808**

 **customerservice@lloytron.com**

 **www.lloytronhelpdesk.com**

thank you

Thank you for the purchase of this quality **HOMELIFE** product. Used carefully and in accordance with the instructions enclosed, it should give you trouble free service over a long period of time. Please keep these instructions for future reference.

FEATURES

- 1W Superbright LED
- Ultra Lightweight Design
- Integral On/Off Switch
- Rechargeable 4v 1Ah Sealed Lead Acid Battery
- Includes AC Mains Charger and 12v Car Charger
- Battery Charging Time: 15hrs approx.
- Usage Time: 3hrs approx.

IMPORTANT SAFEGUARDS AND PRECAUTIONS

SAVE THESE INSTRUCTIONS

When using electrical appliances in general, basic safety precautions should always be observed, including the following;

- Always turn the unit off, when not in use. Leaving it on will shorten the life of the battery.
- The Sealed Lead Acid Battery is not replaceable.
- Should you find the quality of the light deteriorating, recharge the battery using the 12v car adaptor or Mains Adaptor supplied.
- Do not use other adaptors or chargers.
- Do not look directly into the light, this may cause temporary or even permanent blindness.
- The LED Light is not replaceable.
- Ensure the battery is fully charged before first use.
- Do Not leave to charge any longer than 24 hours Max.
- Overcharging can reduce the life expectancy of the battery and the charging unit.

CHARGING

This product is rechargeable and comes complete with built-in rechargeable battery, AC mains charger and 12v car charger.

The spotlight will automatically turn off when the charger is plugged in.

The RED LED will turn on to indicate charging. It does not indicate when fully charged.

Approximate Charging time is 15 hours to full capacity.

Note: *Charging times may vary depending on the source.*



WEEE/ENVIRONMENTAL PROTECTION



■ DISPOSAL OF ELECTRICAL AND ELECTRONIC EQUIPMENT

Do not dispose of this product with household waste. For the proper treatment, recovery and recycling please take this product to the appropriate waste collection point. If you are unsure where this may be, please contact your local authority. Improper disposal may be harmful to the environment.



■ PRODUCT END OF LIFE AND BATTERY DISPOSAL

The built-in rechargeable battery contains substances that may pollute the environment. At end of life for the product, always remove the battery and separate before you discard the product at your local waste collection point. Both battery and product should be disposed separately.

If you have trouble removing the battery, then you should contact a qualified technician or authorised service centre.

Contact your local authority for details and locations of official waste collection points. Do not dispose of batteries or product with normal household waste.

■ REMOVING THE BATTERY

Only remove the rechargeable battery at the time you wish to discard the product.

⊘ DO NOT

Do not remove the battery for any other purposes other than to dispose of the battery and the product separately at an Official Waste Collection Point at the end of the product's life.

1 Using a small cross-head screwdriver, unscrew the screw located on the handle just next to the On/Off switch.

2 Twist the cap that covers the bulb anti-clockwise to expose the reflector and the bulb.

3 There is a small clip located just above the reflector and another small clip located just below the reflector. Release the clips and pry open the plastic casing of the torch.

4 Remove the bulb, reflector and On/Off switch from the plastic casing. Note: the wires will continue to attach these components to the plastic casing. Simply pull the components to one side out of the way.

5 Pry apart the plastic casing until the fixtures holding the battery in place are far apart enough to release the battery.

6 Remove the wires from the battery one at a time.

It is extremely important that you Do Not detach both wires at the same time using scissors, as this could short the battery, resulting in personal injury or damage to the battery.

Dispose of the Rechargeable Battery and the Product separately at an Official Waste Collection Point.





FOR EASY LIVING *homelife*™ **CUSTOMER SERVICES**

If you have any queries about this product, there are three ways to contact our customer service department:

 **08454 81 8808**

 **customerservice@lloytron.com**

 **www.lloytronhelpdesk.com**

To find more details on a wide range of Homelife products please visit our website at **www.lloytron.com**
Lloytron plc, Laltex House, Leigh Commerce Park, Greenfold Way, Leigh, Lancashire, WN7 3XH. England, U.K