

FOR EASY LIVING
homelife[®]

OPERATING INSTRUCTIONS

Nebraska **LED Storm Lamp**



MODEL: D1201CP

thank you

Thank you for the purchase of this quality **HOMELIFE** product. Used carefully and in accordance with the instructions enclosed, it should give you trouble free service over a long period of time. Please keep these instructions for future reference.

FEATURES

- 15x Bright LED's
- Long Life Energy Saving LED's
- Variable Dimmer Settings
- Robust and Weatherproof
- Requires 2 x 'D' Batteries (Not Included)
- Integral Carry Handle

PARTS DESCRIPTION

- A – Integral Carry Handle
B – Battery Compartment (Located underneath the base)
C – On/Off/Dimmer Switch
D – 15x Bright LED's



IMPORTANT SAFEGUARDS AND PRECAUTIONS

SAVE THESE INSTRUCTIONS

- Read all instructions carefully and keep for future reference.
- Do not use rechargeable batteries in this appliance.
- Do not mix old and new batteries, different types of batteries, alkaline or rechargeable batteries with different capacity together – they may leak.
- Always turn the unit off, when not in use. Leaving it on will shorten the life of the batteries.
- If you plan not to use the unit for a length of time, remove the batteries. Old batteries can leak and cause corrosion, damaging the unit.
- The use of long life alkaline batteries is recommended.
- DON'T throw the battery in fire or dispose of in household waste. Consult your local authority in the correct way to dispose of unwanted batteries.
- DON'T short-circuit the supply terminals of the batteries.
- Always check the correct polarity when inserting batteries. Incorrect polarity can damage this unit.

LOCATION OF CONTROLS

1. Remove the battery compartment cover. This is located underneath the base of the lamp.
2. Insert 2 x 'D' Batteries (Not Included), taking care to follow the correct polarity markings on the unit.
3. Reattach the battery compartment cover, being sure that it clicks securely into place.
4. Twist the On/Off/Dimmer Switch clockwise to turn the lamp 'On'. The switch will click to indicate that there is power to the unit.
5. Continue to twist clockwise or anti-clockwise until the desired dimmer setting is achieved.
6. Twist the On/Off/Dimmer switch anti-clockwise until it clicks to turn the lamp 'Off'.

Note: This product is weatherproof from light rain showers. It is not suitable for use in extreme weather conditions. Do Not submerge the lamp in water.

WEEE/ENVIRONMENTAL PROTECTION



DISPOSAL OF ELECTRICAL AND ELECTRONIC EQUIPMENT

Do not dispose of this product with household waste. For the proper treatment, recovery and recycling please take this product to the appropriate waste collection point. If you are unsure where this may be, please contact your local authority. Improper disposal may be harmful to the environment.

FOR EASY LIVING
homelife CUSTOMER SERVICES

If you have any queries about this product then please contact Lloytron Customer Services online at:



www.lloytronhelpdesk.com

To find out more about Homelife products, visit www.lloytron.com



Distributed in UK by Lloytron Ltd, Laltex House, Leigh, England WN7 3XH
Distributed in Europe by Laltex Ireland Ltd, Dublin 2, D02 AY86