

kitchenperfected®

---

OPERATING INSTRUCTIONS

---

# 2 Litre Table Blender

with  
Grinder Mill  
Attachment



---

MODEL: E824BK

---

# thank you

Thank you for the purchase of this quality **Kitchen Perfected** product. Used carefully and in accordance with the instructions enclosed, it should give you trouble free service over a long period of time. Please keep these instructions for future reference.

---

## FEATURES

---

- Power: 500w max
- Capacity: 2 Litre high impact plastic jug
- 2 speed operation
- Pulse function
- Stainless Steel Blades
- Auto clean function
- Grinder Mill Attachment
- Secure lid with safety switch
- Cord Storage Facility
- Safety cut-out
- 60ml Measuring Cup



---

## SPECIFICATIONS

---

- Operating Voltage: 220-240v~50Hz
- Power Output: 500w max.



---

# IMPORTANT SAFEGUARDS AND PRECAUTIONS

---

## SAVE THESE INSTRUCTIONS

- Read all instructions carefully
- For Household Use only. Not intended for commercial use.
- Only for use indoors.

### DO NOT

Do not use outside or in damp conditions.

- Before plugging into mains socket, check whether supply line voltage and current rating are in compliance with the rated electrical parameters shown on the rating label.
- Keep away from hot surfaces, such as gas or electric hobs and ovens etc

### DO NOT

Do not use for any purposes other than the appliances intended use.

- This appliance is not intended to be operated by means of an external timer or separate remote control system.
- To prevent damage to the mains cord, do not let it pass over sharp corners, edges or hot surfaces.
- If the supply cord is damaged, do not use. Check before each use!

**The supply cord cannot be replaced. If the cord is damaged the appliance should be scrapped.**

### DO NOT

Do not use if any part of this appliance is damaged in any way.

- Always unplug when not in use.
- To prevent against the risk of electric shock, do not submerge any part of this appliance in water, unless advised in this manual.
- This appliance should only be used on a flat surface.



- This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.
- Children shall not play with this appliance.
- Cleaning and user maintenance shall not be made by children without supervision.

- Always disconnect the appliance from the supply if it is left unattended and before assembling, disassembling or cleaning.
- Blades are very sharp, even when not in use. Caution should be taken when cleaning or handling blades.
- Ensure correct assembly of all parts before use.
- Blades should be checked regularly for any damage or cracks.

 **DO NOT**

Do not operate in the presence of flammable fumes or mix flammable materials.

 **DO NOT**

Do not allow children to use this appliance without supervision.

 **DO NOT**

Do not use when empty or below the minimum mark.



---

## LOCATION OF CONTROLS

---



### A – Secure Lid

Ensure the lid is securely locked into place before attempting to operate the unit.

### B – 60ml Measuring Cup

This product comes with a detachable 60ml measuring cup that sits in the lid.

### C – Stainless Steel Blades

The stainless steel blades oscillate rapidly to finely chop and blend ingredients.

### D – Motor Unit

The motor unit drives the blades, causing them to oscillate rapidly.

### E – Control Dial

The control allows users to select between 2 speed settings.

### F – Auto clean button

After filling the blender with warm, soapy water, switch the control dial to '0' and press the auto clean button to activate the self cleaning mode.

### G – Pulse button

Press and hold the pulse button to operate the motor in short spurts.

### H – Non Slip Rubber Feet

The non slip rubber feet provide support and stability when blending.

### I – Mains Cord

Connect the mains cord to a suitable 220-240v~50Hz mains power supply.

### J – Grinder Mill Attachment

This model comes with a grinder mill included for coffee beans, spices and nuts.



---

## BEFORE FIRST USE

---

### CAUTION

This appliance operates at very high speeds and is fitted with a safety cut-out switch. **DO NOT CIRCUMVENT THIS SAFETY SWITCH. DO NOT USE CONTINUOUSLY FOR MORE THAN 30 SECONDS.**

Before first use, wash the Jug in warm water, rinse and dry well. Blending is a very fast process. The motor drives the cutter at a high speed to ensure that thorough blending is achieved. Make sure that whenever you use your Blender it is standing on a flat, clean, dry surface. Before starting to blend or grind, please check that the Jug assembly is firmly in place on the motor base.

---

## OPERATION

---


### ■ HOW TO USE YOUR BLENDER



**1 PLACE** the jug onto the motor unit, **ENSURING** the 3 lugs on the motor unit **FIT SECURELY** into the 3 slots underneath the jug.



**2 INSERT** any ingredients into the jug before **ADDING** the liquid. **FIT** the lid onto the top of the jug before **INSERTING** the measuring cup onto the lid. **TURN** the lid **CLOCKWISE** to **LOCK** it into place.



**3** **TURN** the control dial to either **1** (slow speed) or **2** (fast speed) to **OPERATE** the blender.

**4** To use the pulse setting, **KEEP** the control dial on **0** and **PRESS** and **HOLD** the pulse button for short spurts.

**DO NOT**

Do not Overfill past the Max mark.

**CAUTION**

- Do not run the appliance for more than 3 minutes at a time and allow 1-minute intervals between each use. If further use is required after five operations, allow to rest one hour.
- Never place hot ingredients (over 60°C) in the jug.

**IMPORTANT**

DO NOT USE THE PULSE OR CLEAN BUTTON WHILE THE CONTROL KNOB IS IN EITHER THE “1” OR “2” SPEED SETTING.

**TIPS TO PROLONG THE LIFE OF YOUR BLENDER**

**1 MAKE SURE** there is something in the Jug each time you switch “On”. The cutter bearing may be damaged if run on a “No-load” basis.

**2 CUT** cooked meats into one-centimetre cubes **BEFORE ADDING** into the Jug.

**3 REMEMBER** that a blender **CANNOT** process raw meat.

**4 ENSURE** that the food being blended is not too thick or heavy for the motor to handle. If it seems to be having difficulty, **ADD** a little liquid through the lid or **SWITCH OFF**, **REMOVE** the lid and **SCRAPE** the mixture down toward the blade with a soft rubber spatula.

**5 DO NOT** use the Jug for storing foods or beverages.




## ■ HOW TO USE YOUR GRINDER



**1 REMOVE** the transparent cap from the grinder mill by **TWISTING CLOCKWISE**.



**2 INSERT** ingredients such as nuts, coffee beans or spices into the grinder before replacing the cap, **TAKING CARE** not to overfill. **TWIST** the cap **ANTI-CLOCKWISE** to lock it into place.



**3 KEEP** the control dial set to "0" and **PRESS** and **HOLD** the pulse button in **SHORT SPURTS** to **OPERATE** the grinding process.



---

# CLEANING AND CARE

---

## ■ MAINTENANCE

This appliance has been designed to operate over a long period of time with a minimum of maintenance. Continuous satisfactory operation depends upon proper care and regular cleaning.

### WARNING

Before performing any maintenance or cleaning on this appliance, disconnect the appliance from the electricity supply.

## ■ CLEANING YOUR BLENDER

- 1 PLACE** the Jug onto the Motor Base.
- 2 POUR** a little warm soapy water into the Jug.
- 3 TURN** the Control Switch to the "0" position then **PRESS** the 'Auto Clean' button for a few seconds.
- 4 REMOVE** the Jug (or the Mill) and **RINSE** under running water. **REPEAT RINSING** if necessary.
- 5 Wipe** clean the Motor Unit with a damp sponge or cloth: **NEVER IMMERSE IN WATER.**

### CAUTION

- The Motor Base must never be immersed in water or any type of liquid.
- Remove food particles with a soft damp cloth and dry immediately.
- This item is not dishwasher safe.



---

## WEEE/ENVIRONMENTAL PROTECTION

---



### ■ DISPOSAL OF ELECTRICAL AND ELECTRONIC EQUIPMENT


Do not dispose of this product with household waste. For the proper treatment, recovery and recycling please take this product to the appropriate waste collection point. If you are unsure where this may be, please contact your local authority. Improper disposal may be harmful to the environment.



---

## FITTING A NEW UK PLUG

---




Your appliance operates on 220-240V~50Hz AC Mains and comes fitted with a 3-pin BSI Approved plug, so that it is ready for use for the UK or Eire market. If for any reason you need to fit a new plug, the flexible mains lead must be connected as shown below: -

### ■ IMPORTANT:

The wires in the mains lead are coloured in accordance with the following code:

BLUE:	NEUTRAL (N)
BROWN:	LIVE (L)
GREEN AND YELLOW:	EARTH (E)

As the colours of the wires in the mains lead of this appliance may not correspond with the coloured markings identifying the terminals in your plug, proceed as follows:

The BLUE wire must be connected to the terminal which is marked with the letter "N" or coloured BLACK.  
The BROWN wire must be connected to the terminal which is marked with the letter "L" or coloured RED.  
The GREEN AND YELLOW wire must be connected to the terminal which is marked with the letter "E", the symbol  or coloured GREEN.

### ■ DO NOT CONNECT EITHER WIRE 'L' OR 'N' TO THE EARTH TERMINAL OF A 3-PIN PLUG

Always ensure that the Mains Cord is located into the Plug through the Cord Guard or Cable Clamp, and that the Cord Guard screws are tightened to clamp the Cord (outer sheath and inner coloured wires) in position in the Plug. Make sure the Plug top is also fitted securely.

The supply cord cannot be replaced. If the supply cord is damaged, the appliance should be scrapped.

This appliance must be protected by a 5 Amp fuse in a 13 Amp type (BS1363) plug. Should you need to replace the fuse, use only an ASTA approved BS1362 fuse.



---

kitchenperfected **CUSTOMER SERVICES**

---

If you have any queries about this product then please contact Lloytron Customer Services online at:



[www.lloytronhelpdesk.com](http://www.lloytronhelpdesk.com)

To find out more about Kitchen Perfected products, visit [www.lloytron.com](http://www.lloytron.com)



Distributed in UK by Lloytron Plc, Laltex House, Leigh, England WN7 3XH  
Distributed in Europe by Laltex Ireland Ltd, Dublin 2, D02 AY86