
OPERATING INSTRUCTIONS

Advocate

Bankers Desk Lamp



FEATURES

- In-line ON/Off Switch
- Bulb: E27 10w LED GLS or E27 45w max GLS (Bulb not included)
- Height: 37cm approx.

SPECIFICATIONS

Operating Voltage: 220-240v~50Hz

Bulb: E27 10w LED GLS or E27 45w max GLS (Bulb not included)

Ambient Operating Temperature: 5°C to 23°C

Note: Do not operate if ambient temperature is outside this range as this may damage the product.

MODEL: L1162

thank you

Thank you for the purchase of this quality **LLOYTRON** product. Used carefully and in accordance with the instructions enclosed, it should give you trouble free service over a long period of time. Please keep these instructions for future reference.

IMPORTANT SAFEGUARDS AND PRECAUTIONS

SAVE THESE INSTRUCTIONS

- Read all instructions carefully and keep for future reference.
- For Household Use only. Not intended for commercial use.
- Only for use indoors at temperatures between 5°C and 23°C.

DO NOT

- Do not use outside or in damp/wet conditions or in bathrooms.
 - Do not use for any purposes other than the intended use.
 - Do not use this Lamp if damaged.
-
- Before plugging into mains socket, check whether supply line voltage and current rating are in compliance with the rated electrical parameters shown on the rating label.
 - To prevent damage to the mains cord, do not let it pass over sharp corners, edges or hot surfaces.
 - If the power cord is damaged, it must be replaced by the manufacturer or a similarly qualified person in order to avoid a hazard.
 - Any plastic protective cover on the shade must be removed prior to use.
 - Always unplug when not in use.
 - This luminaire should only be used on a flat surface.

WARNING

- This luminaire is not intended to be operated by means of an external timer or separate remote control system.
- This luminaire is not intended for use by persons with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance, by a person responsible for their safety.
- Children should be supervised to ensure they do not play with this luminaire.
- Cleaning and user maintenance shall not be made by children.
- Do not use a lamp of lower voltage than that rated.
- When using low energy lamps such as LED, always ensure they are compatible with the luminaire.
- To prevent against the risk of electric shock, do not submerge any part of this luminaire in water.

HALOGEN BULB REPLACEMENT

Should you need to replace a halogen bulb, allow sufficient time for the bulb and lampshade assembly to cool before you replace.

Never touch the bare bulb with your fingers or hands. Grease or oil from fingers can damage the bulb and cause the bulb to burn out, or drastically reduce its operating life. Instead, always use a soft cloth or facial tissue when handling the bulb. If grease or dirt is seen to get onto the bulb, carefully wipe clean with a lint-free cloth moistened with methylated spirit whilst the luminaire is unplugged.




MINIMUM DISTANCES - LAMP TO OTHER SURFACES

KEEP THE MINIMUM DISTANCE FROM ANY OBJECT - WHEN ILLUMINATED - TO AT LEAST



UK PLUG REWIRING



Your appliance operates on 220-240V~50Hz AC Mains and comes fitted with a 3-pin BSI Approved plug, so that it is ready for use by simply plugging into AC Mains. Should you need to change or refit a plug, proceed as follows: -

■ IMPORTANT:

The wires in the mains lead are coloured in accordance with the following code:

BLUE: NEUTRAL (N)
BROWN: LIVE (L)

As the colours of the wires in the mains lead of this appliance may not correspond with the coloured markings identifying the terminals in your plug, proceed as follows:

The BLUE wire must be connected to the terminal which is marked with the letter "N" or coloured BLACK.
The BROWN wire must be connected to the terminal which is marked with the letter "L" or coloured RED.

■ DO NOT CONNECT EITHER WIRE 'L' OR 'N' TO THE EARTH TERMINAL OF A 3-PIN PLUG

Always ensure that the Mains Cord is located into the Plug through the Cord Guard or Cable Clamp, and that the Cord Guard screws are tightened to clamp the Cord (outer sheath and inner coloured wires) in position in the Plug. Make sure the Plug top is also fitted securely.

The supply cord cannot be replaced. If the supply cord is damaged, the appliance should be scrapped.

This appliance must be protected by a 3 Amp fuse in a 13 Amp type (BS1363) plug. Should you need to replace the fuse, use only an ASTA approved BS1362 fuse.



HOW TO USE

- 1 SCREW IN** one E27 10w LED GLS or E27 45w max GLS (Bulb not included)
- 2 PLUG** into any Household AC Mains Outlet.
- 3 OPERATE** Via the Inline On/Off Switch.

WEEE/ENVIRONMENTAL PROTECTION



■ DISPOSAL OF ELECTRICAL AND ELECTRONIC EQUIPMENT

Do not dispose of this product with household waste. For the proper treatment, recovery and recycling please take this product to the appropriate waste collection point. If you are unsure where this may be, please contact your local authority. Improper disposal may be harmful to the environment.

LLOYTRON® CUSTOMER SERVICES

If you have any queries about this product then please contact Lloytron Customer Services online at:



www.lloytronhelpdesk.com

To find out more about Lloytron products, visit www.lloytron.com

WARRANTY

An additional manufacturer's warranty is not provided with this product. If the product develops a manufacturing fault in any way, then under Statutory Rights you must stop use and return it to the retailer in which it was purchased.



Distributed by Lloytron Plc, Laltex House, Leigh, England WN7 3XH