



OPERATING INSTRUCTIONS

Paper Clip

# 2w Touch LED Desk Lamp



MODEL: L1615

# thank you

Thank you for the purchase of this quality **LLOYTRON** product. Used carefully and in accordance with the instructions enclosed, it should give you trouble free service over a long period of time. Please keep these instructions for future reference.

## FEATURES

- 2w LED (200 lm approx.)
- Foldable Rotating Neck.
- Long Life Energy Saving LED's.
- Touch Sensor Dimmer/On/Off Switch.
- Super Bright Light.
- Variable Dimmer Settings.
- Power by USB or USB Adaptor Provided.

## LOCATION OF CONTROLS

1. Long Life Energy Saving LED's
2. Touch Sensor Dimmer/On/Off Switch
3. USB Input
4. Foldable Rotating Neck





## IMPORTANT SAFEGUARDS AND PRECAUTIONS



### SAVE THESE INSTRUCTIONS


- Read all instructions carefully and keep for future reference.
- For Household Use only. Not intended for commercial use.
- Only for use indoors. Do not use outside or in damp / wet conditions or in bathrooms.
- Before plugging into mains socket, check whether supply line voltage and current rating are in compliance with the rated electrical parameters shown on the rating label.
- Do not use for any purposes other than the appliances intended use.
- This Lamp is not intended to be operated by means of an external timer or separate remote control system.
- To prevent damage to the mains cord, do not let it pass over sharp corners, edges or hot surfaces.
- If the supply cable is damaged, it must be replaced by the manufacturer or a similarly qualified person in order to avoid a hazard.
- Do not use this Lamp if damaged.
- Always unplug when not in use.
- To prevent against the risk of electric shock, Do not submerge any part of the appliance in water.
- This lamp should only be used on a flat surface.
- This lamp is not intended for use by persons with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance, by a person responsible for their safety.
- Children should be supervised to ensure they do not play with this Lamp.
- Cleaning and user maintenance shall not be made by children.
- This lamp uses a non-replaceable low energy LED bulb.
- Do not use any other transformer or mains adaptor to power this lamp.
- Do not dismantle. There are no serviceable parts.
- Always use a soft cloth or facial tissue to clean the lens.
- If the AC/DC adaptor of this luminaire is damaged, it should be replaced by the manufacturer or a similar qualified person in order to avoid hazard.
- Do not point the LED beam directly at eyes.

### PAT TESTING WARNING

This lamp contains a touch sensor and therefore should not be exposed to very high test voltages such as PAT testing, as this could reduce the life of the sensor.

## MINIMUM DISTANCES - LAMP TO OTHER SURFACES

**KEEP THE MINIMUM DISTANCE  
FROM ANY OBJECT - WHEN  
ILLUMINATED - TO AT LEAST**



## HOW TO USE

1. Place the lamp on the desk and adjust the neck to the position required. Please ensure that the neck is not rotated beyond its limited position to avoid causing damage.
2. Using the USB cable provided, connect the lamp to a computer or any other USB compatible powered device, or use the power adaptor provided.
3. Tap the Touch Sensor Switch to operate On/Off.
4. Touch and Hold the Touch Sensor Switch to operate the Dimmer Settings.

NOTE: Do not strain the neck of the lamp by force. This will damage the lamp.

## SPECIFICATIONS

Wattage:	2w Maximum
Lumens:	200 lm approx.
Bulb:	ENERGY SAVING LED (Cannot be replaced)

## LOW VOLTAGE POWER ADAPTOR

This lamp uses a low voltage AC/DC Adaptor for power.  
Only use the adaptor supplied.

Input:	220-240v ~ 50/60Hz
Output:	5v DC 500mA USB

## WEEE/ENVIRONMENTAL PROTECTION



### Disposal of Electrical and Electronic Equipment

Do not dispose of this product with household waste. For the proper treatment, recovery and recycling please take this product to the appropriate waste collection point. If you are unsure where this may be, please contact your local authority. Improper disposal may be harmful to the environment.



## LLOYTRON® CUSTOMER SERVICES

If you have any queries about this product, there are three ways to contact our customer service department:

**call: 08454 81 8808**

**email: [customerservice@lloytron.com](mailto:customerservice@lloytron.com)**

**web: [www.lloytronhelpdesk.com](http://www.lloytronhelpdesk.com)**

To find more details on a wide range of Lloytron products please visit our website at [www.lloytron.com](http://www.lloytron.com)  
Lloytron plc, Laltex House, Leigh Commerce Park, Greenfold Way, Leigh, Lancashire, WN7 3XH. England, U.K